

# EMPIRE®

UPDATED  
12/15/12

## UNIVERSAL TWO-SIDED REPLACEMENT DIGITAL / VIDEO CHARGERS

### Features:

- Reverse Polarity Protection
- Fully Functional - No Plates to Attach
- Quick Charge with 2 Color LED
- 100-240V for Worldwide Travel
- UL with Auto Cut Off for Safety
- Lightweight AC/DC
- Easy to Use with Mounting Instructions
- Countertop/Hanging Clam Packaging
- Covers to Protect Contacts

**LIFETIME  
WARRANTY**

■ SONY   
 ■ CANON   
 ■ PANASONIC   
 ■ KODAK & FUJI & CASIO   
 ■ OLYMPUS & FUJI   
 ■ SAMSUNG  
■ SAMSUNG 2   
 ■ NIKON   
 ■ JVC   
 ■ KONICA / MINOLTA   
 ■ PENTAX & RICOH & SANYO

# SONY

## MODEL DVU-SON1 R1

**NOW CHARGES NP-BX1 (431)**



### SIDE A CHARGES

SONY BATTERIES	EMPIRE	SONY BATTERIES	EMPIRE
<b>A</b> NP-FA50,70	BLI-263	<b>N</b> NP-BN1	BLI-379
<b>D</b> NP-BD1,FD1	BLI-334	<b>P</b> NP-FP30,50,70,90	BLI-246
<b>E</b> NP-FE1	BLI-274	<b>R</b> NP-F R1	BLI-253
<b>G</b> NP-BG1,FG1	BLI-287	<b>T</b> NP-FT1	BLI-247
<b>H</b> NP-FH50,70,100	BLI-308	<b>V</b> NP-FV30,50,70,100	BLI-380
<b>K</b> NP-BK1	BLI-351	<b>X</b> NP-BX1	BLI-431 <b>NEW</b>

### SIDE B CHARGES

SONY BATTERIES	EMPIRE
<b>C</b> NP-FC10,11	BLI-206
<b>F</b> NP-FF50,51,70,71	BLI-209
<b>L</b> NP-F330,550,570,730,750,950	BLI-153
<b>M</b> NP-FM50,70,90,QM71,91	BLI-180
<b>S</b> NP-FS10,11,12,21,22,31,32	BLI-173
<b>W</b> NP-FW50	BLI-395

# CANON

## MODEL DVU-CAN1 R1

**NOW CHARGES BP-709,718, 727 (432)**



### SIDE A CHARGES

CANON BATTERIES	EMPIRE	CANON BATTERIES	EMPIRE
BP-208	BLI-279	NB-4L	BLI-256
BP-308,310,315	BLI-280	NB-5L	BLI-297
BP-709,718,727	BLI-432 <b>NEW</b>	NB-6L	BLI-348
BP-807,809,819,827	BLI-338	NB-7L	BLI-356
BP-808	BLI-376	NB-8L	BLI-378
LP-E5	BLI-350	NB-9L	BLI-398
LP-E10	BLI-415	NB-10L	BLI-420
		NB-11L	BLI-424

### SIDE B CHARGES

CANON BATTERIES	EMPIRE SERIES
BP-110	BLI-429
BP-511,512,522,535	BLI-193
BP-608,617	BLI-169
BP-911,930,945	BLI-161
BP-955,975	BLI-436
LP-E6	BLI-357
LP-E8	BLI-384
NB-1L,1LH	BLI-198
NB-2L,2L12,2L14	BLI-204
NB-3L	BLI-233

# KODAK & FUJI & CASIO

## MODEL DVU-KFC1 R1

**NOW CHARGES CASIO NP-82 (272) NP-90 (374) NP-110 (383) NP-120 (397)**



### SIDE A CHARGES

BATTERIES	EMPIRE	BATTERIES	EMPIRE
KODAK KLIC-7001	BLI-286	CASIO NP-60	BLI-337
KODAK KLIC-7002	BLI-285	CASIO NP-70	BLI-353
KODAK KLIC-7003	BLI-310	CASIO NP-90	BLI-374 <b>NEW</b>
KODAK KLIC-7004	BLI-330	CASIO NP-110	BLI-383 <b>NEW</b>
KODAK KLIC-7005	BLI-321	CASIO NP-120	BLI-397 <b>NEW</b>
CASIO NP-20	BLI-216	FUJI NP-30	BLI-255
CASIO NP-40	BLI-251	FUJI NP-50	BLI-329

### SIDE B CHARGES

BATTERIES	EMPIRE	BATTERIES	EMPIRE
KODAK KLIC-3000	BLI-183	CASIO NP-100	BLI-349
KODAK KLIC-5000	BLI-203	FUJI NP-40,40N	BLI-222
KODAK KLIC-5001	BLI-236	FUJI NP-45	BLI-331
KODAK KLIC-7000	BLI-261	FUJI NP-60	BLI-203
KODAK KLIC-7006	BLI-327	FUJI NP-80	BLI-183
KODAK KLIC-8000	BLI-300	FUJI NP-95	BLI-299
CASIO NP-30	BLI-203	FUJI NP-100	BLI-174
CASIO NP-50	BLI-316	FUJI NP-120	BLI-228
CASIO NP-80	BLI-365	FUJI NP-140	BLI-342
CASIO NP-82	BLI-272 <b>NEW</b>		

# PANASONIC

## MODEL DVU-PAN1 R1

**NOW CHARGES BLE9 (419) VW-VBN130 (423)**



### SIDE A CHARGES

PANASONIC BATTERIES	EMPIRE	PANASONIC BATTERIES	EMPIRE
BLE9	BLI-419 <b>NEW</b>	DMW-BLB13,13E,13PP	BLI-361
CGA-D54S	BLI-262	DMW-BLC12	BLI-417
CGA-DU-07,14,21	BLI-230	DMW-BLD10	BLI-416
CGA-S001,1E,DMW-BCA7	BLI-226	DMW-BLE9	BLI-419
CGR-D120,220,320	BLI-172	DMW-BMB9	BLI-404
CGR-S602A,603	BLI-218	VBG-070,130,260	BLI-307
DMW-BCF10,BCF10E	BLI-367	VW-VBD19	BLI-396
DMW-BCG10,10E,10PP	BLI-368	VW-VBG6	BLI-393
DMW-BCH7	BLI-391	VW-VBK180,360	BLI-400
DMW-BCJ13	BLI-403	VW-VBN130,260	BLI-423 <b>NEW</b>
DMW-BCK7	BLI-418		

### SIDE B CHARGES

PANASONIC BATTERIES	EMPIRE
CGA-S002	BLI-225
CGA-S003	BLI-237
CGA-S005	BLI-284
CGA-S007,007E	BLI-298
CGA-S008E,VBJ10	BLI-319
CGA-S302	BLI-241
CGR-S006A,006E,DMW-BMA7	BLI-283
CGR-S101A,B,DMW-BC7	BLI-219
VW-VBA10,12	BLI-203

# OLYMPUS & FUJI

## MODEL DVU-OLF1 R1

NOW CHARGES  
Li70B (389)  
Li80B (269)



### SIDE A CHARGES

BATTERIES	EMPIRE	BATTERIES	EMPIRE
OLYMPUS BLM-1	BLI-240	OLYMPUS Li50B	BLI-339
OLYMPUS BLS-1	BLI-306	OLYMPUS Li60B	BLI-355
OLYMPUS BLM-5	BLI-407	OLYMPUS Li70B	BLI-389
OLYMPUS BLS-5	BLI-409 <b>NEW</b>	OLYMPUS Li80B	BLI-269
OLYMPUS Li10B,12B	BLI-224	FUJI NP-45	BLI-331
OLYMPUS Li30B	BLI-257	FUJI NP-140	BLI-342
OLYMPUS Li40B,42B	BLI-272		

### SIDE B CHARGES

BATTERIES	EMPIRE	BATTERIES	EMPIRE
OLYMPUS Li20B	BLI-203	FUJI NP-80	BLI-183
FUJI NP-30	BLI-255	FUJI NP-95	BLI-299
FUJI NP-40	BLI-222	FUJI NP-100	BLI-174
FUJI NP-50	BLI-329	FUJI NP-120	BLI-228
FUJI NP-60	BLI-203	FUJI NP-150	BLI-317
FUJI NP-70	BLI-301		

# NIKON

## MODEL DVU-NIK1 R1

NOW CHARGES  
EN-EL19 (413)  
EN-EL20 (422)



### SIDE A CHARGES

NIKON BATTERIES	EMPIRE SERIES
EN-EL12	BLI-354
EN-EL14	BLI-401
EN-EL15	BLI-406
EN-EL19	BLI-413 <b>NEW</b>
EN-EL20	BLI-422 <b>NEW</b>

### SIDE B CHARGES

NIKON BATTERIES	EMPIRE SERIES	NIKON BATTERIES	EMPIRE SERIES
EN-EL1,1H	BLI-201	EN-EL7	BLI-267
EN-EL2	BLI-210	EN-EL8	BLI-275
EN-EL3,3a	BLI-211	EN-EL9,9A	BLI-304
EN-EL3e	BLI-293	EN-EL10	BLI-320
EN-EL5	BLI-239	EN-EL11	BLI-345

# SAMSUNG

## MODEL DVU-SAM1 R1

NOW CHARGES  
SLB-0637 (259),  
SLB-1137C (318),  
BP-85ST (335) AND  
SLB-0937 (332),  
SLB-1137D (314),  
SLB-10A (341)



### SIDE A CHARGES

SAMSUNG BATTERIES	EMPIRE SERIES
BP-85ST	BLI-335
SB-P90,P180	BLI-282
SB-P120,P240	BLP-302
SLB-0637	BLI-259
SLB-0737	BLI-222
SLB-0837	BLI-288
SLB-1137C	BLI-318
SLB-1437	BLI-268

### SIDE B CHARGES

SAMSUNG BATTERIES	EMPIRE SERIES	SAMSUNG BATTERIES	EMPIRE SERIES
BP1030	BLI-421 <b>NEW</b>	SLB-0837B	BLI-303
SB-L70,L110,220	BLI-200	SLB-0937	BLI-332
SB-L160,320,480	BLI-195	SLB-10A	BLI-341
SB-LH73	BLI-305	SLB-11A	BLI-370
SB-LH82	BLI-296	SLB-1137D	BLI-314
SB-LS110,220	BLI-278	SLB-1237	BLI-295
SB-LSM80,160,320	BLI-271		

# SAMSUNG 2

## MODEL DVU-SAM2

NEW SECOND GENERATION SAMSUNG CHARGER



### SIDE A CHARGES

SAMSUNG BATTERIES	EMPIRE SERIES	SAMSUNG BATTERIES	EMPIRE SERIES
BP-1310	BLI-386	BP-88B	BLI-434 <b>NEW</b>
BP-70A	BLI-382	IA-BH125C	BLI-371
BP-85A	BLI-412	IA-BH130LB	BLI-373
BP-90A	BLI-405	IA-BP80W	BLI-352
BP-125A	BLI-390	IA-BP80WA	BLI-377
BP-210E,420E	BLI-411	SLB-07A,B	BLI-366
BP-88A	BLI-428 <b>NEW</b>		

# PENTAX & RICOH & SANYO

## MODEL DVU-PRS1 R1

**NOW CHARGES**  
PENTAX D-Li85,  
D-Li90, D-Li95,  
D-Li106  
RICOH DB-90, 100  
SANYO DB-L90



### SIDE A CHARGES

BATTERIES	EMPIRE	BATTERIES	EMPIRE
PENTAX D-Li50	BLI-238	RICOH DB-100	BLI-364
PENTAX D-Li63	BLI-311	RICOH DS-6365	BLI-331
PENTAX D-Li78	BLI-344	SANYO DB-L10	BLI-224
PENTAX D-Li88	BLI-363	SANYO DB-L40	BLI-294
PENTAX D-Li90	BLI-372	SANYO DB-L80	BLI-363
PENTAX D-Li92	BLI-364	SANYO DB-L90	BLI-387
RICOH DB-50	BLI-300	SANYO DS-5370	BLI-272
RICOH DB-80	BLI-344		

### SIDE B CHARGES

BATTERIES	EMPIRE	BATTERIES	EMPIRE
PENTAX D-Li1	BLI-208	RICOH DB-34	BLI-228
PENTAX D-Li2	BLI-203	RICOH DB-40	BLI-203
PENTAX D-Li7	BLI-228	RICOH DB-43	BLI-228
PENTAX D-Li8	BLI-222	RICOH DB-60 DB-65	BLI-284
PENTAX D-Li68	BLI-333	RICOH DB-70	BLI-323
PENTAX D-Li72	BLI-259	RICOH DB-90	BLI-299
PENTAX D-Li85, D-Li95	BLI-222	SANYO DB-L20	BLI-244
PENTAX D-Li106	BLI-371	SANYO DB-L30	BLI-259
PENTAX D-Li122	BLI-333 <b>NEW</b>	SANYO DB-L50	BLI-236
RICOH DB-20	BLI-183	SANYO NP-40	BLI-222
RICOH DB-30	BLI-174		

# JVC

## MODEL DVU-JVC1 R1

**NOW CHARGES**  
BN-VG 107,  
114,121  
(392)



### SIDE A CHARGES

JVC BATTERIES	EMPIRE BATTERY SERIES
BN-V37,37U	
BN-V107,114	BLI-202
BN-V408,416,428,438	BLI-192
BN-V707,714,733	BLI-270
BN-VG107,114,121	BLI-392 <b>NEW</b>

### SIDE B CHARGES

JVC BATTERIES	EMPIRE BATTERY SERIES
BN-V712	BLI-160
BN-V812,814	BLI-162
BN-VF808,815,823	BLI-309
BN-VF908	BLI-394 <b>NEW</b>
BN-VM200	BLI-265

# KONICA/MINOLTA

## MODEL DVU-KOM1

**NOW SHIPPING**



### SIDE A CHARGES

KONICA/MINOLTA BATTERIES	EMPIRE BATTERY SERIES
DR-LB4	BLI-223
NP-1	BLI-281
NP-200	BLI-217
NP-400	BLI-238
NP-500/600	BLI-243
NP-700	BLI-259
NP-900	BLI-269

### MAXIMUM CHARGING TIME FOR ALL CHARGERS

VOLT	CAPACITY	TIME
3.6/3.7V	500 mAh	1 Hour
3.6/3.7V	1000 mAh	2 Hours
7.2/7.4V	1000 mAh	2 Hours
7.2/7.4V	2000 mAh	4 Hours

**EMPIRE CENTRAL**  
1501 Tonne Ave.  
Elk Grove Village, IL 60007  
Phone: (800) 221-6012  
Fax: (800) 719-9902

**HEADQUARTERS**  
P.O. Box 817  
151 East Industry Court  
Deer Park, NY 11729-5713  
Phone: (800) 645-7220  
Fax: (800) 343-5733

**EMPIRE SOUTH**  
4504 E. Hillsborough Ave.  
Tampa, FL 33610  
Phone: (800) 810-8891  
Fax: (877) 422-8866

**VISIT US ON THE WEB:** [www.empirescientific.com](http://www.empirescientific.com)  
**E-MAIL:** [sales@empirescientific.com](mailto:sales@empirescientific.com)