

MANY NEW
MODELS
AVAILABLE

EMPIRE®

REVISED
1/11

VBC SERIES AC/DC VIDEO/DIGITAL BATTERY CHARGERS

SPECIAL
100-240V
CHARGER

Now 100-240V AT THE
SAME LOW PRICE

IDEAL FOR TRAVEL



Our VBC Lithium-Ion Video/Digital Battery Charger is packed with all these great advantages:

- UL with reverse polarity protection, with overheating and overcharge protection
- Many new items available – Always first to market
- Consumer friendly – Easy to use – No confusing plates to mount
- Two color LED indicates charging status and full charge
- Deluxe clam packaging with 12V car adapter and 100-240V wall transformer
- Simple numbering system – Charger number matches Empire battery number**
- Most batteries achieve 80% capacity in under 2 hours
- New, smaller footprint takes up less space on your desk or in your camera bag

**Example: The VBC-256P Charger will charge the Empire BLI-256 battery

Call if your model is not listed – NEW MODELS ADDED MONTHLY

EMPIRE CENTRAL

1501 Tonne Ave.
Elk Grove Village, IL 60004
Phone: (800) 221-6012
Fax: (800) 719-9902

HEADQUARTERS

P.O. Box 817
151 East Industry Court
Deer Park, NY 11729-5713
Phone: (800) 645-7220
Fax: (800) 343-5733

EMPIRE SOUTH

4504 E. Hillsborough Ave.
Tampa, FL 33610
Phone: (800) 810-8891
Fax: (877) 422-8866

VISIT US ON THE WEB: www.empirescientific.com ● E-MAIL: sales@empirescientific.com

EMPIRE® VBC Series Video/Digital Battery Chargers

V	VBC-6V/JPS	4.8V/6V NiCd & NiMH JVC, PANASONIC, SONY - ALL CAPACITIES
V	VBC-109P	USE VBC-6V/JPS
V	VBC-150P	USE VBC-6V/JPS
D V	VBC-153P	SONY NP-F550,750,950 "L" SIZE
D V	VBC-153/180P	SONY NP-FM30/50/70/90, F330/550/750/950
V	VBC-155P	USE VBC-6V/JPS
D V	VBC-156P	SHARP BT-L1/L2/L12/L21
V	VBC-158P	USE VBC-164P
V	VBC-159P	USE VBC-6V/JPS
D	VBC-160P	JVC BN-V712
V	VBC-161P	CANON BP-914,927
D V	VBC-162P	JVC BN-V812, PANASONIC AG-BP15
V	VBC-164P	SHARP BT,H22,H32, H42
V	VBC-166P	HITACHI VMBPL13,27
V	VBC-169P	CANON BP-608,617
V	VBC-170P	JVC BN-V607,615
D V	VBC-172P	PANASONIC CGR-D120,220
D	VBC-173P	SONY NP-F10,11 "S" SIZE
D	VBC-174P	FUJI NP-100
V	VBC-175P	JVC BN-V507,514
V	VBC-176P	SHARP BT-L221/L241/L441
V	VBC-177P	SHARP BT-L221U (USE VBC-176P)
D V	VBC-180P	SONY NP-FM50,70,90
V	VBC-181P	PANASONIC CGR-V610,620
V	VBC-182P	JVC BN-V207,214
D	VBC-183P	KODAK KLIC3000/FUJI NP80
V	VBC-192P	JVC BN-V406,416,428
D V	VBC-193P	CANON BP-511,522
V	VBC-195P	SAMSUNG SB-L160,320,480
V	VBC-196P	SHARP BT-L223
D	VBC-197P	JVC BN-V37
D	VBC-198P	CANON NB-1L
V	VBC-199P	CANON BP-406,412,422
V	VBC-200P	SAMSUNG SB-L110, L220
D	VBC-201P	NIKON EN-EL1
V	VBC-202P	JVC BN-V107, V114
D	VBC-203P	FUJI NP-60
D V	VBC-204P	CANON NB-2L
V	VBC-205P	SHARP BT-L225/L445
D	**VBC-206P	SONY NP-FC10
D	VBC-207P	YASHICA, KYOCERA BP800S, BP880S
V	VBC-209P	SONY NP-FF50/FF70
D	VBC-210P	NIKON EN-EL2
D	VBC-211P	NIKON EN-EL3
V	VBC-214P	SHARP BT-LS222U (USE VBC-176)
D	VBC-216P	CASIO NP-20
D	VBC-217P	MINOLTA NP-200
D	VBC-218P	PANASONIC CGR-S602A
D	VBC-219P	PANASONIC CGA-S101A
V	VBC-220P	JVC BN-V306U/312U
D	VBC-222P	SANYO, FUJI NP-40
D	VBC-223P	KONICA DR-LB4
D	VBC-224P	OLYMPUS LiB10
D	VBC-225P	PANASONIC CGR-S002, DMW-BM7
D	VBC-226P	PANASONIC CGA-S001, DMW-BCA7
D	VBC-228P	FUJI NP-120, RICOH DB-43
V	VBC-229P	SHARP BT-L226U
V	VBC-230P	HITACHI DZ-BP07S, PAN.CGA-DU07
D	VBC-233P	CANON NB-3L
D	VBC-236P	KODAK KLIC-5001
D	VBC-237P	PANASONIC CGA-S003
D	VBC-238P	KONICA, MINOLTA NP-400
D	VBC-239P	NIKON EN-EL5
D	VBC-240P	OLYMPUS BLM-1
D	VBC-241P	PANASONIC CGA-S302
D	VBC-243P	KONICA, MINOLTA NP-500/600
D	VBC-244P	SANYO SL20, FISHER DB-L20
D	VBC-245P	KYOCERA, YASHICA BP-780S
V	VBC-246P	SONY NP-FP50/70/90
D	VBC-247P	SONY NP-FT1
D	VBC-251P	CASIO NP-40
D	VBC-253P	SONY NP-FR1
D	VBC-255P	FUJI NP-30
D	VBC-256P	CANON NB-4L
D	VBC-257P	OLYMPUS Li30B
D	VBC-259P	MINOLTA NP-700, SANYO DB-L30
D	VBC-260P	PANASONIC DMW-BCB7/S004
D	VBC-261P	KODAK KLIC-7000
V	VBC-262P	PANASONIC CGA-D54
V	VBC-263P	SONY NP-FA50/70
V	VBC-264P	KYOCERA / CONTAX BP-760S
D V	VBC-265P	JVC BN-VM200U
D	VBC-266P	EPSON EU-94
D	VBC-267P	NIKON EN-EL7
D	VBC-268P	SAMSUNG SLB-1437
D	VBC-269P	KONICA, MINOLTA NP-900
V	VBC-270P	JVC BN-V707/714/733
V	VBC-271P	SAMSUNG SB-LS80/LSM80/LSM160
D	VBC-272P	OLYMPUS Li40B, CASIO NP-82
D	VBC-273P	USE VBC-CRV3 KIT
D	VBC-274P	SONY NP-FE1
D	VBC-275P	NIKON EN-EL8
D V	VBC-276P	KYOCERA/CONTAX BP-1100S
V	VBC-277P	USE VBC-300P
V	VBC-278P	SAMSUNG SB-LS110
V	VBC-279P	CANON BP-208
V	VBC-280P	CANON BP-308, 315
D	VBC-281P	KONICA/MINOLTA NP-1
V	VBC-282P	SAMSUNG SB-P90A, P180A
D	VBC-283P	PANASONIC DMW-BMA7/S006E
D	VBC-284P	PANASONIC DMW-BCC12/S005E
D	VBC-285P	KODAK KLIC-7002
D	VBC-286P	KODAK KLIC-7001
D	VBC-287P	SONY NP-BG-1
D	VBC-288P	SAMSUNG SLB-0837
D	VBC-289P	SAMSUNG SLB-1974
D	VBC-290P	PANASONIC CGA-S303
D	VBC-293P	NIKON EN-EL3e
D	VBC-294P	SANYO DB-L40
D	VBC-295P	SAMSUNG SLB-1237
D	VBC-296P	SAMSUNG SB-LH82
D	VBC-297P	CANON NB-5L
D	VBC-298P	PANASONIC DMW-BCD10/S007E
D	**VBC-299P	FUJI NP-95
D	VBC-300P	KODAK KLIC-8000
D	VBC-301P	FUJI NP-70
D	VBC-302P	SAMSUNG SB-P120/P240
D	VBC-303P	SAMSUNG SLB-0837B
D	VBC-304P	NIKON EN-EL9,9A
D	VBC-305P	SAMSUNG SB-LH73 (USE VBC-295P)
D	VBC-306P	OLYMPUS PS-BLS1
D V	VBC-307P	PANASONIC VV-VBG-130K,260K
D V	VBC-308P	SONY NP-FH50/70/90
V	VBC-309P	JVC BN-V808/815/823
D	VBC-310P	KODAK KLIC-7003
D	VBC-311P	PENTAX D-Li63
D	VBC-314P	SAMSUNG SLB-1137D
D	VBC-315P	VIVITAR 83005, 8330, 8600
D	VBC-316P	CASIO NP-50
D	VBC-317P	FUJI NP150
D	VBC-318P	SAMSUNG SLB-1137C
D	VBC-319P	PANASONIC DMW-BCE10/S008E
D	VBC-320P	NIKON EN-EL10
D	VBC-321P	KODAK KLIC-7005
D	VBC-323P	RICOH DB-70
D	VBC-324P	VIVITAR 6330S
D	VBC-325P	GE GB-40 (USE VBC-310P)
D	VBC-326P	GE GB-20 (USE VBC-310P)
D	VBC-327P	KODAK KLIC-7006
D	VBC-328P	POLAROID M635 (USE VBC-285P)
D	VBC-329P	FUJI NP-50 (USE VBC-285P)
D	VBC-330P	KODAK KLIC-7004 (USE VBC-285P)
D	VBC-331P	FUJI NP-45 (USE VBC-272P)
D	VBC-332P	SAMSUNG 0937
D	VBC-333P	PENTAX D-Li68 (USE VBC-285P)
D	VBC-334P	SONY NP-BD1 (USE VBC-247P)
V	VBC-335P	SAMSUNG IA-BP85ST
D	VBC-337P	CASIO NP-60
V	VBC-338P	CANON BP-807,808,809,819,827
D	VBC-339P	OLYMPUS Li50B
D	VBC-341P	SAMSUNG SLB-10A,11A
D	VBC-342P	FUJI NP-140
V	VBC-343P	SAMSUNG IA-BP85SW
D	VBC-344P	PENTAX D-Li78, RICOH DB80
D	VBC-345P	NIKON EN-EL11
D	VBC-348P	CANON NB-6L
D	VBC-349P	CASIO NP-100
D	VBC-350P	CANON LP-E5
D	VBC-351P	USE VBC-287P
V	VBC-352P	SAMSUNG IA-BP80W
D	VBC-353P	CASIO NP-70
D	VBC-354P	NIKON EN-EL12
D	VBC-355P	OLYMPUS Li60B
D	VBC-356P	CANON NB-7L
D	VBC-361P	PANASONIC DMW-BLB13/13E/13PP (USE VBC-230P)
D	VBC-363P	PENTAX D-Li88, SANYO DB-L80 (USE VBC-287P)
D	VBC-364P	PENTAX D-Li92 (USE VBC-287P)
D	VBC-365P	CASIO NP-80 (USE VBC-272P)
D	VBC-366P	SAMSUNG SLB-07A (USE VBC-296P)
D	VBC-367P	PANASONIC DMW-BCF10/10E (USE VBC-368P)
D	VBC-368P	PANASONIC DMW-BCG10/10E/10PP
V	VBC-370P	SAMSUNG SLB-11A (USE VBC-341P)
V	VBC-376P	CANON BP-808 (USE VBC-338P)
V	VBC-377P	SAMSUNG IA-BP80WA (USE VBC-352P)
D	VBC-378P	CANON NB-8L (USE VBC-256P)
V	VBC-380P	SONY NP-FV SERIES (USE VBC-308P)
D	VBC-382P	SAMSUNG BP-70A (USE VBC-287P)
D	VBC-383P	CASIO NP-110 (USE VBC-367P)
D	VBC-384P	CANON LP-E8 (USE VBC-204P)
D	VBC-387P	SANYO DB-L90 (USE VBC-294P)
D	VBC-391P	PANASONIC DMW-BCH7 (USE VBC-298P)
V	VBC-392P	JVC BN-VG107, VG114, VG121
V	VBC-394P	JVC BN-VF908 (USE VBC-309P)
D	VBC-395P	SONY NP-FW50 (USE VBC-246P)
V	VBC-396P	PANASONIC VV-VBD19 (USE VBC-172P)

KEY **D** Used with Digital Cameras **V** Charges NiMH & NiCd Batteries **V** Used with Video Cameras ****** Also Charges 2 x AA and 2 x AAA NiMH

In most cases USE information applies to current generation chargers as additions are constantly being made.

VISIT US ON THE WEB: www.empirescientific.com • E-MAIL: sales@empirescientific.com