

EMPIRE®

UNIVERSAL TWO-SIDED REPLACEMENT DIGITAL/VIDEO CHARGERS

UPDATED 3/23/09
NOW SHIPPING
UPDATED
MODELS




Features:

- Reverse Polarity Protection
- Fully Functional - No Plates to Attach
- Quick Charge with 2 Color LED
- 100-240V for Worldwide Travel
- UL with Auto Cut Off for Safety
- Lightweight AC/DC
- Easy to Use with Mounting Instructions
- Countertop/Hanging Clam Packaging
- Covers to Protect Contacts

LIFETIME WARRANTY

MAXIMUM CHARGING TIME FOR ALL CHARGERS

| VOLT | CAPACITY | TIME |
|----------|----------|---------|
| 3.6/3.7V | 500 mAh | 1 Hour |
| 3.6/3.7V | 1000 mAh | 2 Hours |
| 7.2/7.4V | 1000 mAh | 2 Hours |
| 7.2/7.4V | 2000 mAh | 4 Hours |



SONY
 CANON
 PANASONIC
 KODAK & FUJI & CASIO
 OLYMPUS & FUJI
 SAMSUNG
 NIKON
 JVC
 KONICA / MINOLTA
 PENTAX & RICOH & SANYO

EMPIRE CENTRAL

381 Randy Road
 Carol Stream, IL 60188
 Phone: (800) 221-6012
 Fax: (800) 719-9902

HEADQUARTERS

P.O. Box 817
 151 East Industry Court
 Deer Park, NY 11729-5713
 Phone: (800) 645-7220
 Fax: (800) 343-5733

EMPIRE SOUTH

4504 E. Hillsborough Ave.
 Tampa, FL 33610
 Phone: (800) 810-8891
 Fax: (877) 422-8866

VISIT US ON THE WEB: www.empirescientific.com ● E-MAIL: sales@empirescientific.com

SONY

CANON

PANASONIC

KODAK & FUJI & CASIO

OLYMPUS & FUJI

DVU-SON1 R1

DVU-CAN1 R1

DVU-PAN1 R1

DVU-KFC1 R1

DVU-OLF1 R1



| | SONY | EMPIRE |
|-------------------------------|---------------------|--------------|
| SIDE A | A NP-FA50,70 | BLI-263 |
| | D NP-BD1,FD1 | BLI-334 |
| | E NP-FE1 | BLI-274 |
| | G NP-BG1 | BLI-287 |
| | H NP-FH50,70,100 | BLI-308 |
| | K NP-BK1 NEW | BLI-351 |
| | P NP-FP30,50,70,90 | BLI-246 |
| | R NP-FR1 | BLI-253 |
| | T NP-FT1 | BLI-247 |
| | SIDE B | C NP-FC10,11 |
| F NP-FF50,51,70,71 | | BLI-209 |
| L NP-F330,550,570,730,750,950 | | BLI-153 |
| M NP-FM50,70,90,QM71,91 | | BLI-180 |
| S NP-FS10,11,12,21,22,31,32 | | BLI-173 |

| | CANON | EMPIRE |
|--------|-----------------------|---------|
| SIDE A | BP-208 | BLI-279 |
| | BP-308,310,315 | BLI-280 |
| | BP-808,809 NEW | BLI-338 |
| | LP-E5 NEW | BLI-350 |
| | NB-4L | BLI-256 |
| | NB-5L | BLI-297 |
| | NB-6L NEW | BLI-348 |
| | BP-511,512,522,535 | BLI-193 |
| | BP-608,617 | BLI-169 |
| | BP-911,930,945 | BLI-161 |
| SIDE B | NB-1L,1LH | BLI-198 |
| | NB-2L,2L12,2L14 | BLI-204 |
| | NB-3L | BLI-233 |

| | PANASONIC | EMPIRE |
|--------|-------------------------|---------|
| SIDE A | CGA-D54S | BLI-262 |
| | CGA-DU-07,14,21 | BLI-230 |
| | CGA-S001,1E,DMW-BCA7 | BLI-226 |
| | CGA-S303 | BLI-290 |
| | CGR-D120,220,320 | BLI-172 |
| | CGR-S602A,603 | BLI-218 |
| | VBG-130,260 | BLI-307 |
| | CGA-S002 | BLI-225 |
| | CGA-S003 | BLI-237 |
| | CGA-S005 | BLI-284 |
| SIDE B | CGA-S007,007E | BLI-298 |
| | CGA-S008E NEW | BLI-319 |
| | CGA-S302 | BLI-241 |
| | CGR-S006A,006E,DMW-BMA7 | BLI-283 |
| | CGR-S101A,B,DMW-BC7 | BLI-219 |
| | VV-VBA10,12 | BLI-203 |

| | KODAK & CASIO & FUJI | EMPIRE |
|--------|----------------------------|---------|
| SIDE A | KODAK KLIC-7001 | BLI-286 |
| | KODAK KLIC-7002 | BLI-285 |
| | KODAK KLIC-7003 | BLI-310 |
| | KODAK KLIC-7004 | BLI-330 |
| | KODAK KLIC-7005 | BLI-321 |
| | CASIO NP-20 | BLI-216 |
| | CASIO NP-40 | BLI-251 |
| | CASIO NP-60 NEW | BLI-337 |
| | FUJI NP-30 | BLI-255 |
| | FUJI NP-50 | BLI-329 |
| SIDE B | KODAK KLIC-3000 | BLI-183 |
| | KODAK KLIC-5000 | BLI-203 |
| | KODAK KLIC-5001 | BLI-236 |
| | KODAK KLIC-7000 | BLI-261 |
| | KODAK KLIC-7006 NEW | BLI-327 |
| | KODAK KLIC-8000 NEW | BLI-300 |
| | CASIO NP-30 | BLI-203 |
| | CASIO NP-50 NEW | BLI-316 |
| | CASIO NP-100 NEW | BLI-349 |
| | FUJI NP-40,40N | BLI-222 |
| SIDE B | FUJI NP-45 NEW | BLI-331 |
| | FUJI NP-60 | BLI-203 |
| | FUJI NP-80 | BLI-183 |
| | FUJI NP-95 | BLI-299 |
| | FUJI NP-100 | BLI-174 |
| | FUJI NP-120 | BLI-228 |
| | FUJI NP-140 NEW | BLI-342 |

| | OLYMPUS & FUJI | EMPIRE |
|--------|--------------------------|---------|
| SIDE A | OLYMPUS BLM-1 | BLI-240 |
| | OLYMPUS BLS-1 | BLI-306 |
| | OLYMPUS Li10B,12B | BLI-224 |
| | OLYMPUS Li30B | BLI-257 |
| | OLYMPUS Li40B,42B | BLI-272 |
| | OLYMPUS Li50B NEW | BLI-339 |
| | FUJI NP-45 NEW | BLI-331 |
| | FUJI NP-140 NEW | BLI-342 |
| | OLYMPUS Li20B NEW | BLI-203 |
| | OLYMPUS Li60B NEW | BLI-355 |
| SIDE B | FUJI NP-30 NEW | BLI-255 |
| | FUJI NP-40 | BLI-222 |
| | FUJI NP-50 NEW | BLI-329 |
| | FUJI NP-60 | BLI-203 |
| | FUJI NP-70 NEW | BLI-301 |
| | FUJI NP-80 | BLI-183 |
| | FUJI NP-95 | BLI-299 |
| | FUJI NP-100 | BLI-174 |
| | FUJI NP-120 | BLI-228 |
| | FUJI NP-150 NEW | BLI-317 |

SAMSUNG

NIKON

JVC

KONICA/ MINOLTA

PENTAX & RICOH & SANYO

DVU-SAM1 R1

DVU-NIK1 R1

DVU-JVC1

DVU-KOM1

DVU-PRS1



| | SAMSUNG | EMPIRE |
|----------------------|----------------------|---------|
| SIDE A | BP-85ST NEW | BLI-335 |
| | SB-P90,P180 | BLI-282 |
| | SB-P120,P240 | BLP-302 |
| | SLB-0637 NEW | BLI-259 |
| | SLB-0737 | BLI-222 |
| | SLB-0837 | BLI-288 |
| SIDE B | SLB-1137C NEW | BLI-318 |
| | SLB-1437 | BLI-268 |
| | SB-L70,L110,220 | BLI-200 |
| | SB-L160,320,480 | BLI-195 |
| | SB-LH73 | BLI-305 |
| | SB-LH82 | BLI-296 |
| | SB-LS110,220 | BLI-278 |
| | SB-LSM80,160,320 | BLI-271 |
| | SLB-0837B | BLI-303 |
| | SLB-0937 NEW | BLI-332 |
| SLB-10A NEW | BLI-341 | |
| SLB-1137D NEW | BLI-314 | |
| SLB-1237 | BLI-295 | |

| | NIKON | EMPIRE |
|--------|--------------------|---------|
| SIDE A | EN-EL12 NEW | BLI-354 |
| | EN-EL1,1H | BLI-201 |
| | EN-EL2 | BLI-210 |
| | EN-EL3,3a | BLI-211 |
| | EN-EL3e | BLI-293 |
| | EN-EL5 | BLI-239 |
| | EN-EL7 | BLI-267 |
| | EN-EL8 | BLI-275 |
| | EN-EL9 | BLI-304 |
| | EN-EL10 NEW | BLI-320 |
| SIDE B | EN-EL11 NEW | BLI-345 |

| | JVC | EMPIRE |
|--------|---------------------|---------|
| SIDE A | BN-V37,37U | |
| | BN-V408,416,428,438 | BLI-192 |
| | BN-V707,714,733 | BLI-270 |
| | BNV-107,114 | BLI-202 |
| | BN-V712 | BLI-160 |
| | BN-V812,814 | BLI-162 |
| | BN-VF808,815,823 | BLI-309 |
| | BN-VM200 | BLI-265 |

| | KONICA/MINOLTA | EMPIRE |
|--------|----------------|---------|
| SIDE A | DR-LB4 | BLI-223 |
| | NP-1 | BLI-281 |
| | NP-200 | BLI-217 |
| | NP-400 | BLI-238 |
| | NP-500/600 | BLI-243 |
| | NP-700 | BLI-259 |
| | NP-900 | BLI-269 |

| | PENTAX & RICOH & SANYO | EMPIRE |
|---------------|------------------------|--------------|
| SIDE A | PENTAX D-Li50 | BLI-238 |
| | PENTAX D-Li63 | BLI-311 |
| | PENTAX D-Li78 | BLI-344 |
| | RICOH DB-50 | BLI-300 |
| | RICOH DB-80 | BLI-344 |
| | RICOH DS-6365 | BLI-331 |
| | SANYO DB-L10 | BLI-224 |
| | SANYO DB-L40 | BLI-294 |
| | SANYO DS-5370 | BLI-272 |
| | SIDE B | PENTAX D-Li1 |
| PENTAX D-Li2 | | BLI-203 |
| PENTAX D-Li7 | | BLI-228 |
| PENTAX D-Li8 | | BLI-222 |
| PENTAX D-Li68 | | BLI-333 |
| PENTAX D-Li72 | | BLI-259 |
| RICOH DB-20 | | BLI-183 |
| RICOH DB-30 | | BLI-174 |
| RICOH DB-34 | | BLI-228 |
| RICOH DB-40 | | BLI-203 |
| SIDE B | RICOH DB-43 | BLI-228 |
| | RICOH DB-60 | BLI-284 |
| | RICOH DB-70 | BLI-323 |
| | SANYO DB-L20 | BLI-244 |
| | SANYO DB-L30 | BLI-259 |
| | SANYO DB-L50 | BLI-236 |
| | SANYO NP-40 | BLI-222 |