

Contact Us :

## VBC Series Video/Digital Battery Chargers

Phone

NY : 1 (800) 645-7220  
IL : 1 (800) 221-6012  
FL : 1 (800) 810-8891

Fax

NY : 1 (800) 343-5733  
IL : 1 (800) 719-9902  
FL : 1 (877) 422-8866

Visit Us On The Web:

[www.empirescientific.com](http://www.empirescientific.com)

Email:

[sales@empirescientific.com](mailto:sales@empirescientific.com)

For More Information,  
Call or E-Mail us Today!



**CALL FOR  
PRICING!**



Now Charges  
Many NiCd  
NiMh 3.6V, 6V  
JVC, Panasonic  
Sony, Sharp

Our new VBC Lithium-Ion Video/Digital Battery Charger is packed with all these great advantages:

- ▶ SIMPLE NUMBERING SYSTEM – CHARGER NUMBER MATCHES EMPIRE BATTERY NUMBER\*\*
- ▶ MANY NEW ITEMS AVAILABLE – ALWAYS FIRST TO MARKET
- ▶ NEW, SMALLER FOOTPRINT TAKES UP LESS SPACE ON YOUR DESK OR IN YOUR CAMERA BAG
- ▶ SPACE-AGE PLASTIC MAKES IT LIGHTER TO CARRY, YET MORE DURABLE
- ▶ DELUXE PACKAGE WITH 12V CAR ADAPTOR AND 120V WALL TRANSFORMERS
- ▶ AVAILABLE WITH OPTIONAL 100/240V ADAPTOR FOR USE OVERSEAS
- ▶ MOST BATTERIES ACHIEVE 80% CAPACITY IN UNDER 2 HOURS
- ▶ LOWER PRICE POINT MEANS GREATER GROSS PROFIT MARGINS
- ▶ CONSUMER FRIENDLY – EASY TO USE – NO CONFUSING PLATES TO MOUNT
- ▶ TWO COLOR LED INDICATES CHARGING STATUS AND FULL CHARGE

\*\* EXAMPLE: THE **VBC-256P** CHARGER WILL CHARGE THE EMPIRE **BLI-256** BATTERY

Top 10 Sellers (descending order): 203, 270, 224, 256, 204, 230, 198, 192, 192, 246

**CALL NOW ! 1-800-645-7220**

© 2007 Empire Scientific. All Rights Reserved

LS-21 1/3

# Empire Chargers

Page 1 of 2

**[D]** = Used with **Digital** Cameras    **[V]** = Charges **NiCd & NiMh**    **[V]** = Used with **Video** Cameras    **[D]** **[V]** = Used in **both Digital and Video** Cameras

<b>[V]</b>	<b>VBC-6V/JPS</b>	4.8V/6V NiCd & NiMh JVC, PANASONIC, SONY - ALL CAPACITIES	<b>[D]</b>	VBC-198P	CANON NB-1L
<b>[V]</b>	VBC-109P	<b>USE VBC-6V/JPS</b>	<b>[V]</b>	VBC-199P	CANON BP-406,412,422
<b>[V]</b>	VBC-150P	<b>USE VBC-6V/JPS</b>	<b>[V]</b>	VBC-200P	SAMSUNG SB-L110, L220
<b>[D]</b> <b>[V]</b>	VBC-153P	SONY NP-F550,750,950 "L" SIZE	<b>[D]</b>	VBC-201P	NIKON COOLPIX 880, 995
<b>[D]</b> <b>[V]</b>	VBC-153/180P	SONY NP-FM30/50/70/90,F330/550/750/950	<b>[V]</b>	VBC-202P	JVC BN-V107, V114
<b>[V]</b>	VBC-155P	<b>USE VBC-6V/JPS</b>	<b>[D]</b>	VBC-203P	FUJI NP-60
<b>[D]</b> <b>[V]</b>	VBC-156P	SHARP BT-L1/L2/L11/L12	<b>[D]</b>	VBC-204P	CANON NB-2L
<b>[V]</b>	VBC-158P	<b>USE VBC-164P</b>	<b>[V]</b>	VBC-205P	SHARP BT-L225/L445
<b>[V]</b>	VBC-159P	<b>USE VBC-6V/JPS</b>	<b>[D]</b>	VBC-206P	SONY NP-FC10
<b>[D]</b>	VBC-160P	JVC BN-V712	<b>[D]</b>	VBC-207P	YASHICA, KYOCERA BP800S, BP880S
<b>[V]</b>	VBC-161P	CANON BP-914,927	<b>[D]</b>	VBC-208P	PENTAX DLi1, HPC912
<b>[D]</b> <b>[V]</b>	VBC-162P	JVC BN-V812, PANASONIC AG-BP15	<b>[V]</b>	VBC-209P	SONY NP-FF50/FF70
<b>[V]</b>	VBC-164P	SHARP BT-H11,H22,H32,H42	<b>[D]</b>	VBC-210P	NIKON EN-EL2
<b>[V]</b>	VBC-166P	HITACHI VMBPL13,27	<b>[D]</b>	VBC-211P	NIKON D100
<b>[V]</b>	VBC-169P	CANON BP-608,617	<b>[V]</b>	VBC-214P	SHARP BT-LS222U (USE VBC-176)
<b>[V]</b>	VBC-170P	JVC BN-V607,615	<b>[D]</b>	VBC-216P	CASIO NP-20
<b>[D]</b> <b>[V]</b>	VBC-172P	PANASONIC CGR-D120,220	<b>[D]</b>	VBC-217P	MINOLTA NP-200
<b>[D]</b>	VBC-173P	SONY NP-F10,11 "S" SIZE	<b>[D]</b>	VBC-218P	PANASONIC CGR-S602A
<b>[D]</b>	VBC-174P	FUJI NP-100	<b>[D]</b>	VBC-219P	PANASONIC CGA-S101A
<b>[V]</b>	VBC-175P	JVC BN-V507,514	<b>[V]</b>	VBC-220P	JVC BN-V306U/312U
<b>[V]</b>	VBC-176P	SHARP BT-L221/L241/L441	<b>[D]</b>	VBC-221P	SANYO UR-121
<b>[V]</b>	VBC-177P	SHARP BT-I221U (USE VBC-176P)	<b>[D]</b>	VBC-222P	FUJI NP-40
<b>[D]</b> <b>[V]</b>	VBC-180P	SONY NP-FM50,70,90	<b>[D]</b>	VBC-223P	KONICA DR-LB4
<b>[V]</b>	VBC-181P	PANASONIC CGR-V610,620	<b>[D]</b>	VBC-224P	OLYMPUS LiB10
<b>[V]</b>	VBC-182P	JVC BN-V207,214	<b>[D]</b>	VBC-225P	PANASONIC CGR-S002, DMW-BM7
<b>[D]</b>	VBC-183P	KODAK KLIC3000/FUJI NP80	<b>[D]</b>	VBC-226P	PANASONIC CGA-S001, DMW-BCA7
<b>[V]</b>	VBC-192P	JVC BN-V406,416,428	<b>[D]</b>	VBC-228P	FUJI NP-120, RICOH DB-43
<b>[D]</b> <b>[V]</b>	VBC-193P	CANON BP-511,522	<b>[V]</b>	VBC-229P	SHARP BT-L226U
<b>[V]</b>	VBC-195P	SAMSUNG SB-L160,320,480	<b>[V]</b>	VBC-230P	HITACHI DZ-BP07S, PANASONIC CGA-DU07
<b>[V]</b>	VBC-196P	SHARP BT-L223	<b>[D]</b>	VBC-233P	CANON NB-3L
<b>[D]</b>	VBC-197P	JVC BN-V37	<b>[D]</b>	VBC-236P	KODAK KLIC-5001

# Empire Chargers

[D] = Used with Digital Cameras    [V] = Charges NiCd & NiMh    [V] = Used with Video Cameras    [D] [V] = Used in both Digital and Video Cameras

[D]	VBC-237P	PANASONIC CGA-S003	[D]	VBC-287P	SONY NP-BG-1
[D]	VBC-238P	KONICA, MINOLTA NP-400	[D]	VBC-288P	SAMSUNG SLB-0837
[D]	VBC-239P	NIKON EN-EL5	[D]	VBC-289P	SAMSUNG SLB-1974
[D]	VBC-240P	OLYMPUS BLM-1	[D]	VBC-290P	PANASONIC CGA-S303
[D]	VBC-241P	PANASONIC CGA-S302	[D]	VBC-293P	NIKON EN-EL 3e
[D]	VBC-243P	KONICA, MINOLTA NP-500/600	[D]	VBC-294P	SANYO DB-I40
[D]	VBC-244P	SANYO SL20, FISHER DB-L20	[D]	VBC-295P	SAMSUNG SLB-1237
[D]	VBC-245P	KYOCERA, YASHICA BP-780S	[D]	VBC-296P	SAMSUNG SB-LH82
[V]	VBC-246P	SONY NP-FP50/70/90	[D]	VBC-297P	CANON NB-5L
[D]	VBC-247P	SONY NP-FT1	[D]	VBC-298P	PANASONIC DMW-BCD10/S007E
[D]	VBC-251P	CASIO NP-40	[D]	**VBC-299P	FUJI NP-95
[D]	VBC-253P	SONY NP-FR1	[D]	VBC-300P	KODAK KLIC-8000
[D]	VBC-255P	FUJI NP-30	[D]	VBC-301P	FUJI NP-70
[D]	VBC-256P	CANON NB-4L	[D]	VBC-302P	SAMSUNG SB-P120/P240
[D]	VBC-257P	OLYMPUS Li30B	[D]	VBC-303P	SAMSUNG SLB-0837B
[D]	VBC-259P	MINOLTA NP-700, SANYO DB-L30	[D]	VBC-304P	NIKON ENEL9
[D]	VBC-261P	KODAK KLIC-7000	[D]	VBC-305P	SAMSUNG SB-LH73 (USE VBC-295P)
[V]	VBC-262P	PANASONIC CGA-D54	[D]	VBC-306P	OLYMPUS PS-BLS1
[V]	VBC-263P	SONY NP-FA50/70	[V]	VBC-307P	PANASONIC VW-VBG-130K,260K
[V]	VBC-264P	KYOCERA / CONTAX BP-760S	[V]	VBC-308P	SONY NP-FH50/70/90
[D][V]	VBC-265P	JVC BN-VM200U	[V]	VBC-309P	JVC BN-V808/815/823
[D]	VBC-267P	NIKON EN-EL7	[D]	VBC-310P	KODAK KLIC-7003
[D]	VBC-268P	SAMSUNG SLB-1437	[D]	VBC-311P	PENTAX D-Li63
[D]	VBC-269P	KONICA, MINOLTA NP-900	[D]	VBC-314P	SAMSUNG SLB-1137D
[V]	VBC-270P	JVC BN-V707/714/733	[D]	VBC-315P	VIVITAR 83005, 8330, 8600
[V]	VBC-271P	SAMSUNG SB-LS80/LSM80/LSM160	[D]	VBC-316P	CASIO NP-50
[D]	VBC-272P	OLYMPUS Li40B	[D]	VBC-317P	FUJI NP150
[D]	VBC-274P	SONY NP-FE1	[D]	VBC-319P	PANASONIC DMW-BCE10/S008E
[D]	VBC-275P	NIKON EN-EL8	[D]	VBC-320P	NIKON EN-EL10
[D][V]	VBC-276P	KYOCERA / CONTAX BP-1100S	[D]	VBC-321P	KODAK KLIC-7005
[V]	VBC-277P	<b>USE VBC-300P</b>	[D]	VBC-324P	VIVITAR 6330S
[V]	VBC-278P	SAMSUNG SB-LS110	[D]	VBC-325P	GE GB-40 (USE VBC-310P)
[V]	VBC-279P	CANON BP-208	[D]	VBC-326P	GE GB-20 (USE VBC-310P)
[V]	VBC-280P	CANON BP-308, 315	[D]	VBC-327P	KODAK KLIK-7006
[D]	VBC-281P	KONICA / MINOLTA NP-1	[D]	VBC-328P	POLAROID M635 (USE VBC-285P)
[V]	VBC-282P	SAMSUNG SB-P90A, P180A	[D]	VBC-329P	FUJI-NP50 (USE VBC-285P)
[D]	VBC-283P	PANASONIC DMW-BMA7/S006E	[D]	VBC-330P	KODAK KLIC-7004 (USE VBC-285P)
[D]	VBC-284P	PANASONIC DMW-BCC12/S005E	[D]	VBC-331P	FUJI NP45, RICOH 6365 (USE VBC-272P)
[D]	VBC-285P	KODAK KLIC-7002	[D]	VBC-333P	PENTAX D-Li68 (USE VBC-285P)
[D]	VBC-286P	KODAK KLIC-7001	[D]	VBC-334P	SONY NP-BD1 (USE VBC-247P)
			[V]	<b>VBC-6V/JPS</b>	4.8V/6V NiCD & NiMh JVC, PAN, SONY - ALL

\*\* = ALSO CHARGES 2 x AA or 2 x AAA NiMh

ALL CHARGERS AVAILABLE IN SPECIAL 100-240V TRAVEL VERSION **FOR AN ADDITIONAL \$7.00 EACH.**  
JUST ADD "/220" SUFFIX TO MODEL NUMBER WHEN ORDERING (FOR EXAMPLE: VBC-153P/220).