

# EMPIRE®

## UNIVERSAL TWO-SIDED REPLACEMENT DIGITAL/VIDEO CHARGERS

UPDATED 11/8/08  
NOW SHIPPING  
UPDATED  
MODELS



### Features:

- Reverse Polarity Protection
- Fully Functional - No Plates to Attach
- Quick Charge with 2 Color LED
- 100-240V for Worldwide Travel
- UL with Auto Cut Off for Safety
- Lightweight AC/DC
- Easy to Use with Mounting Instructions
- Countertop/Hanging Clam Packaging
- Covers to Protect Contacts

## LIFETIME WARRANTY

### MAXIMUM CHARGING TIME FOR ALL CHARGERS

VOLT	CAPACITY	TIME
3.6/3.7V	500 mAh	1 Hour
3.6/3.7V	1000 mAh	2 Hours
7.2/7.4V	1000 mAh	2 Hours
7.2/7.4V	2000 mAh	4 Hours



SONY
  CANON
  PANASONIC
  KODAK & FUJI & CASIO
  OLYMPUS & FUJI
  SAMSUNG
  NIKON
  JVC
  KONICA / MINOLTA
  PENTAX & RICOH & SANYO

### EMPIRE CENTRAL

381 Randy Road  
Carol Stream, IL 60188  
Phone: (800) 221-6012  
Fax: (800) 719-9902

### HEADQUARTERS

P.O. Box 817  
151 East Industry Court  
Deer Park, NY 11729-5713  
Phone: (800) 645-7220  
Fax: (800) 343-5733

### EMPIRE SOUTH

4504 E. Hillsborough Ave.  
Tampa, FL 33610  
Phone: (800) 810-8891  
Fax: (877) 422-8866

VISIT US ON THE WEB: [www.empirescientific.com](http://www.empirescientific.com) ● E-MAIL: [sales@empirescientific.com](mailto:sales@empirescientific.com)

# SONY

# CANON

# PANASONIC

# KODAK & FUJI & CASIO

# OLYMPUS & FUJI

## DVU-SON1 R1

## DVU-CAN1 R1

## DVU-PAN1 R1

## DVU-KFC1 R1

## DVU-OLF1 R1



	SONY	EMPIRE
SIDE A	A NP-FA50,70	BLI-263
	D NP-BD1,FD1	BLI-334
	E NP-FE1	BLI-274
	G NP-BG1	BLI-287
	H NP-FH50,70,100	BLI-308
	K NP-BK1 <b>NEW</b>	BLI-351
	P NP-FP30,50,70,90	BLI-246
	R NP-FR1	BLI-253
	T NP-FT1	BLI-247
	SIDE B	C NP-FC10,11
F NP-FF50,51,70,71		BLI-209
L NP-F330,550,570,730,750,950		BLI-153
M NP-FM50,70,90,QM71,91		BLI-180
S NP-FS10,11,12,21,22,31,32		BLI-173

	CANON	EMPIRE
SIDE A	BP-208	BLI-279
	BP-308,310,315	BLI-280
	BP-808,809 <b>NEW</b>	BLI-338
	LP-E5 <b>NEW</b>	BLI-350
	NB-4L	BLI-256
	NB-5L	BLI-297
	NB-6L <b>NEW</b>	BLI-348
	BP-511,512,522,535	BLI-193
	BP-608,617	BLI-169
	BP-911,930,945	BLI-161
SIDE B	NB-1L,1LH	BLI-198
	NB-2L,2L12,2L14	BLI-204
	NB-3L	BLI-233

	PANASONIC	EMPIRE
SIDE A	CGA-D54S	BLI-262
	CGA-DU-07,14,21	BLI-230
	CGA-S001,1E,DMW-BCA7	BLI-226
	CGA-S303	BLI-290
	CGR-D120,220,320	BLI-172
	CGR-S602A,603	BLI-218
	VBG-130,260	BLI-307
	CGA-S002	BLI-225
	CGA-S003	BLI-237
	CGA-S005	BLI-284
SIDE B	CGA-S007,007E	BLI-298
	CGA-S008E <b>NEW</b>	BLI-319
	CGA-S302	BLI-241
	CGR-S006A,006E,DMW-BMA7	BLI-283
	CGR-S101A,B,DMW-BC7	BLI-219
	VV-VBA10,12	BLI-203

	KODAK & CASIO & FUJI	EMPIRE
SIDE A	KODAK KLIC-7001	BLI-286
	KODAK KLIC-7002	BLI-285
	KODAK KLIC-7003	BLI-310
	KODAK KLIC-7004	BLI-330
	KODAK KLIC-7005	BLI-321
	CASIO NP-20	BLI-216
	CASIO NP-40	BLI-251
	CASIO NP-60 <b>NEW</b>	BLI-337
	FUJI NP-30	BLI-255
	FUJI NP-50	BLI-329
SIDE B	KODAK KLIC-3000	BLI-183
	KODAK KLIC-5000	BLI-203
	KODAK KLIC-5001	BLI-236
	KODAK KLIC-7000	BLI-261
	KODAK KLIC-7006 <b>NEW</b>	BLI-327
	KODAK KLIC-8000 <b>NEW</b>	BLI-300
	CASIO NP-30	BLI-203
	CASIO NP-50 <b>NEW</b>	BLI-316
	CASIO NP-100 <b>NEW</b>	BLI-349
	FUJI NP-40,40N	BLI-222
SIDE B	FUJI NP-45 <b>NEW</b>	BLI-331
	FUJI NP-60	BLI-203
	FUJI NP-80	BLI-183
	FUJI NP-95	BLI-299
	FUJI NP-100	BLI-174
	FUJI NP-120	BLI-228
	FUJI NP-140 <b>NEW</b>	BLI-342

	OLYMPUS & FUJI	EMPIRE
SIDE A	OLYMPUS BLM-1	BLI-240
	OLYMPUS BLS-1	BLI-306
	OLYMPUS Li10B,12B	BLI-224
	OLYMPUS Li30B	BLI-257
	OLYMPUS Li40B,42B	BLI-272
	OLYMPUS Li50B <b>NEW</b>	BLI-339
	FUJI NP-45 <b>NEW</b>	BLI-331
	FUJI NP-140 <b>NEW</b>	BLI-342
	OLYMPUS Li20B <b>NEW</b>	BLI-203
	OLYMPUS Li60B <b>NEW</b>	BLI-355
SIDE B	FUJI NP-30 <b>NEW</b>	BLI-255
	FUJI NP-40	BLI-222
	FUJI NP-50 <b>NEW</b>	BLI-329
	FUJI NP-60	BLI-203
	FUJI NP-70 <b>NEW</b>	BLI-301
	FUJI NP-80	BLI-183
	FUJI NP-95	BLI-299
	FUJI NP-100	BLI-174
	FUJI NP-120	BLI-228
	FUJI NP-150 <b>NEW</b>	BLI-317

# SAMSUNG

# NIKON

# JVC

# KONICA/ MINOLTA

# PENTAX & RICOH & SANYO

## DVU-SAM1 R1

## DVU-NIK1 R1

## DVU-JVC1

## DVU-KOM1

## DVU-PRS1



	SAMSUNG	EMPIRE
SIDE A	BP-85ST <b>NEW</b>	BLI-335
	SB-P90,P180	BLI-282
	SB-P120,P240	BLP-302
	SLB-0637 <b>NEW</b>	BLI-259
	SLB-0737	BLI-222
	SLB-0837	BLI-288
	SLB-1137C <b>NEW</b>	BLI-318
SIDE B	SLB-1437	BLI-268
	SB-L70,L110,220	BLI-200
	SB-L160,320,480	BLI-195
	SB-LH73	BLI-305
	SB-LH82	BLI-296
	SB-LS110,220	BLI-278
	SB-LSM80,160,320	BLI-271
	SLB-0837B	BLI-303
	SLB-0937 <b>NEW</b>	BLI-332
	SLB-10A <b>NEW</b>	BLI-341
SLB-1137D <b>NEW</b>	BLI-314	
SLB-1237	BLI-295	

	NIKON	EMPIRE
SIDE A	EN-EL1,1H	BLI-201
	EN-EL2	BLI-210
	EN-EL3,3a	BLI-211
	EN-EL3e	BLI-293
	EN-EL5	BLI-239
	EN-EL7	BLI-267
	EN-EL8	BLI-275
	EN-EL9	BLI-304
	EN-EL10 <b>NEW</b>	BLI-320
	EN-EL11 <b>NEW</b>	BLI-345

	JVC	EMPIRE
SIDE A	BN-V37,37U	
	BN-V408,416,428,438	BLI-192
	BN-V707,714,733	BLI-270
	BNV-107,114	BLI-202
	BN-V712	BLI-160
	BN-V812,814	BLI-162
	BN-VF808,815,823	BLI-309
	BN-VM200	BLI-265

	KONICA/MINOLTA	EMPIRE
SIDE A	DR-LB4	BLI-223
	NP-1	BLI-281
	NP-200	BLI-217
	NP-400	BLI-238
	NP-500/600	BLI-243
	NP-700	BLI-259
	NP-900	BLI-269

	PENTAX & RICOH & SANYO	EMPIRE
SIDE A	PENTAX D-Li50	BLI-238
	PENTAX D-Li63	BLI-311
	PENTAX D-Li78	BLI-344
	RICOH DB-50	BLI-300
	RICOH DB-80	BLI-344
	RICOH DS-6365	BLI-331
	SANYO DB-L10	BLI-224
	SANYO DB-L40	BLI-294
	SANYO DS-5370	BLI-272
	SIDE B	PENTAX D-Li1
PENTAX D-Li2		BLI-203
PENTAX D-Li7		BLI-228
PENTAX D-Li8		BLI-222
PENTAX D-Li68		BLI-333
PENTAX D-Li72		BLI-259
RICOH DB-20		BLI-183
RICOH DB-30		BLI-174
RICOH DB-34		BLI-228
RICOH DB-40		BLI-203
SIDE B	RICOH DB-43	BLI-228
	RICOH DB-60	BLI-284
	RICOH DB-70	BLI-319
	SANYO DB-L20	BLI-244
	SANYO DB-L30	BLI-259
	SANYO DB-L50	BLI-236
	SANYO NP-40	BLI-222