

# EMPIRE®

## UNIVERSAL LI-ION CHARGER FOR MOST 3.6-7.4V LITHIUM-ION BATTERIES

**AUTO  
POLARITY  
DETECT**

**UNIQUE SLIDING CONTACT DESIGN  
Model: USC-001**

**ADJUSTABLE  
SLIDING  
CONTACTS**

**CHARGES:** Digital Camera,  
Camcorder, Cell Phone, PDA, MP3, GPS,  
and Most Other Lithium-ion Batteries



### FEATURES:

- Auto Polarity Detection - No Reverse Polarity Problems
- Adjustable Contacts Allow for Proper Alignment
- Includes Plastic Wand for Easy Contact Adjustment
- Overcharge Protection With Automatic Current Control
- Rapid Charge with 800mAh Adapter - Many 3.6V Batteries Will Charge in 1 Hour
- Charge Status Indicator with Faulty Battery Indicator
- Short Circuit Protection and Overheat Protection
- 2 Year Warranty

### SPECIFICATIONS:

- Charges Only Li-ion or Li-Polymer Batteries 3.6 – 7.4V
- AC – 100 – 240V 800mAh For International Travel
- DC Cord Included

### MAXIMUM CHARGING TIMES:

VOLT	CAPACITY	TIME
3.6 / 3.7V	500 mAh	1 Hour
3.6 / 3.7V	1000 mAh	2 Hours
7.2 / 7.4V	1000 mAh	2 Hours
7.2 / 7.4V	2000 mAh	4 Hours



### VERTICAL MOUNT:



Use for Most 3.6–3.7V Cellular  
and Digital Camera Batteries

### HORIZONTAL MOUNT:



Use for Most 7.2–7.4V Camcorder  
and Other Batteries

### EMPIRE CENTRAL

1501 Tonne Ave.  
Elk Grove Village, IL 60007  
Phone: (800) 221-6012  
Fax: (800) 719-9902

### HEADQUARTERS

P.O. Box 817  
151 East Industry Court  
Deer Park, NY 11729-5713  
Phone: (800) 645-7220  
Fax: (800) 343-5733

### EMPIRE SOUTH

4504 E. Hillsborough Ave.  
Tampa, FL 33610  
Phone: (800) 810-8891  
Fax: (877) 422-8866

VISIT US ON THE WEB: [www.empirescientific.com](http://www.empirescientific.com) ● E-MAIL: [sales@empirescientific.com](mailto:sales@empirescientific.com)

LS31-USC-R1